

INSTRUCTION for HTC EVO

1. How to make a call

For international call

0037—611 + Country code + Area Code + Number + “#”

For Domestic call

0037-611 + JAPANESE Phone Number + “#”

(0037-61-03-1234-5678#, 0037-61-080-2345-0987#)

or

You use Direct Phone Number, it will cost 42JPY/Min.

03-3456-1234 or 080-1234-1234 etc.

2. Sending SMS to outside Japan costs 100Yen/ SMS, We recommend you use e-mail instead.

3. Wifi tethering setting

- 1) Go to Setting > Wireless & Network.
- 2) Go to Wifi tethering setting. Get WAP code.
- 3) Go back to Wireless & Network. Select WIMAX(40MBPS)
- 4) Select Wifi tethering

4. Keyboard.

This phone is configured in English, but can input Japanese. If you use only English, please check input mode bottom left of keyboard.

“文字”.

あ A 1 Please select A or 1 for English input.

5. Reset Phone.

For your security, please reset the phone when you return it.

Setting>SD&Phone storage>Factory data reset

Please turn over

6. Extra battery

HTC EVO supports WiFi tethering, but uses more battery life. We advise using an extra battery.

1) Charge a battery

Connect AC charger and battery, then insert to outlet.

Charge time:7hrs

2) Charge a HTC EVO

Connect battery and HTC EVO with USB cable.

Turn on the battery to start charging.

Takes about 2hrs for full charge

7. Support Center

Phone 080-3452-7100

-Prohibited Actions -

-Do not install jailbreak. If you do, we will costs (Recovery, All of packet transfer fee etc.)

-Do not use outside Japan. If you do, you will be charged the appropriate roaming fees.

Check List for return

Before returning the device, please check that the following items are included:

- 1) Phone body
- 2) Apple USB Power Adapter
- 3) Dock Connector to USB Cable
- 4) Extra battery
- 5) Instruction manual

Please turn over